



# MCUXSDKUSBCOMDUG

MCUXpresso SDK USB Stack Composite Device User's Guide

Rev. 13 — 11 July 2022

User guide

## Document information

Information	Content
Keywords	MCUXSDKUSBCOMDUG, USB Stack, Composite Device
Abstract	This document describes steps to implement a composite device based on the USB stack.



## 1 Overview

This document describes steps to implement a composite device based on the USB stack.

The USB Stack provides five composite device demos, *HID+audio*, *MSC+CDC*, *MSC\_SDCARD+CDC*, *CDC\_VCOM+CDC\_VCOMAND*, and *mouse+keyboard*. The users can create composite devices to fit their needs. This document is a step-by-step guide to create a customizable composite device.

## 2 Introduction

A composite device combines multiple independent functionalities by unifying its code into one implementation. For example, the single functionality code for CDC is provided in the CDC example and the single functionality code for MSC is provided in the MSC example. Creating the CDC+MSC composite device example requires combining the CDC example code and MSC example code into a single example.

Composite device descriptors are combined from the single-function device descriptors. There are two single-function devices. Each device has an interface descriptor in a configuration descriptor. If the composite device is combined using two single function devices, the interface descriptor of each device should be merged into the composite device configuration descriptor.

Implementing a composite device involves combining the descriptors and the functionalities of the single function devices.

## 3 Setup

Before developing the composite device, the user needs to:

1. Decide how many classes are included in this composite device.
2. Decide which types of classes are included in this composite device. For example, HID + AUDIO, HID + HID, and so on.
3. Prepare the device descriptor depending on the use case. In particular, the IAD should be used for AUDIO/VIDEO class. For more information, see [www.usb.org/developers/docs/whitepapers/iadclasscode\\_r10.pdf](http://www.usb.org/developers/docs/whitepapers/iadclasscode_r10.pdf).
4. Ensure that the functionality of the single function device code is valid.

### 3.1 Design steps

1. A new composite device application should use the existing examples as a template.
2. Prepare the descriptor-related data structure to ensure that the correct information about the customized composite device is related to the USB device stack. See [Section 4](#) for additional information.
3. Prepare the descriptors array and ensure that the descriptors are consistent with the descriptor-related data structure. See [Section 5](#).
4. Implement the specific descriptor-related callback function which the USB device stack calls to get the device descriptor. See [Section 5](#).

## 4 USB composite device structures

The USB composite device structures are defined in the USB stack code. The structures describe the class and are consistent with the descriptor. They are also used in single function examples.

### 4.1 usb\_device\_class\_config\_list\_struct\_t

This structure is required for the composite device and relays device callback, class callback, interface numbers, and endpoint numbers of each interface to the class driver. The structure should be placed in the “composite.c” file.

This is an example for a composite device MSD + CDC:

```
usb_device_class_config_list_struct_t  
g_compositeDeviceConfigList =  
{  
    .config = g_compositeDevice,  
    .deviceCallback = USB_DeviceCallback,  
    .count = 2,  
};
```

The variable “count” holds the number of classes included in the composite device. Because the composite device MSD+CDC includes two classes, the value of variable “count” is 2.

The type of “config” is `usb_device_class_config_struct_t`. See subsequent sections for more information.

### 4.2 usb\_device\_class\_config\_struct\_t

This structure is required for the composite device and provides information about each class. The structure should be placed in the “composite.c” file.

This is an example for the composite device MSD + CDC:

```
usb_device_class_config_struct_t g_compositeDevice[2] =  
{  
    {  
        .classCallback = USB_DeviceCdcVcomCallback,  
        .classHandle = (class_handle_t) NULL,  
        .classInfomation = &g_UsbDeviceCdcVcomConfig,  
    },  
    {  
        .classCallback = USB_DeviceMscCallback,  
        .classHandle = (class_handle_t) NULL,  
        .classInfomation = &g_mscDiskClass,  
    }  
};
```

`classCallback` is the callback function pointer of each class.

`classHandle` is the class handle. This value is NULL and updated by the `USB_DeviceClassInit` function.

The type of `classInfomation` is `usb_device_class_struct_t`, including the configuration count, class type, and the interface list for this class.

### 4.3 usb\_device\_class\_struct\_t

This structure is required for each class including the class type, supported configuration count, and interface list for each configuration. The structure should be placed in the “usb\_device\_descriptor.c” file.

This is an example for MSD in the composite MSD + CDC device example.

```
usb_device_class_struct_t g_mscDiskClass =
{
    .interfaceList = g_mscDiskInterfaceList,
    .type = kUSB_DeviceClassTypeMsc,
    .configurations = USB_DEVICE_CONFIGURATION_COUNT,
};
```

*interfaceList* is the interface list pointer, which points to the type `usb_device_interface_list_t`. It includes detailed interface information about the class including interface count, alternate setting count for each interface, and ep count, ep type, and ep direction for each alternate setting. See subsequent sections for more information.

*Type* represents the type of each class included in the composite device. For example, the type of MSD class is `kUSB_DeviceClassTypeMsc`.

*Configurations* member indicates the count of the class supported.

### 4.4 usb\_device\_interface\_list\_t

This structure is required for the composite device and provides information about each class. The structure should be placed in the “usb\_device\_descriptor.c” file.

This is an example for MSC in the composite MSC + CDC device example.

```
usb_device_interface_list_t
g_mscDiskInterfaceList[USB_DEVICE_CONFIGURATION_COUNT] =
{
{
    .count = USB_MSC_DISK_INTERFACE_COUNT,
    .interfaces = g_mscDiskInterfaces,
},
};
```

*Count* indicates the interface count this class supports in each configuration.

*Interfaces* member indicates the interface list for each configuration.

### 4.5 usb\_device\_interfaces\_struct\_t

This structure provides alternate setting interface information about each interface. All structures should be placed in the “usb\_device\_descriptor.c” file.

**Prototype:**

```
typedef struct _usb_device_interfaces_struct
{
    uint8_t
        classCode;
    uint8_t
        subclassCode;
    uint8_t
        protocolCode;
```

```

    uint8_t                                interfaceNumber;
    usb_device_interface_struct_t*          interface;
    uint8_t                                count;
} usb_device_interfaces_struct_t;

```

**Description:**

- classCode: The class code for this interface.
- subclassCode: The subclass code for this interface.
- protocolCode: The protocol code for this interface.
- interfaceNumber: Interface index in the interface descriptor.
- interface: Includes detailed information about the current interface. For details, see subsequent chapters.
- count: Number of interfaces in the current interface.

This is an example for the composite device MSD + CDC:

MSD:

```

usb_device_interfaces_struct_t
g_mscDiskInterfaces[USB_MSC_DISK_INTERFACE_COUNT] =
{
    {
        USB_MSC_DISK_CLASS,
        USB_MSC_DISK_SUBCLASS,
        USB_MSC_DISK_PROTOCOL,
        USB_MSC_DISK_INTERFACE_INDEX,
        g_mscDiskInterface,
        sizeof(g_mscDiskInterface) /
        sizeof(usb_device_interface_struct_t),
    }
};

```

`USB_MSC_DISK_INTERFACE_INDEX` is the interface index of this interface in a current configuration. In other words, in the interface descriptor, the interface number is `USB_MSC_DISK_INTERFACE_INDEX`.

“`g_mscDiskInterface`” is the interface detailed information structure. See [Section 4.6](#) section for more information.

CDC:

```

usb_device_interfaces_struct_t
g_cdcVcomInterfaces[USB_CDC_VCOM_INTERFACE_COUNT] =
{
    {
        USB_CDC_VCOM_CIC_CLASS,
        USB_CDC_VCOM_CIC_SUBCLASS,
        USB_CDC_VCOM_CIC_PROTOCOL,
        USB_CDC_VCOM_CIC_INTERFACE_INDEX,
        g_cdcVcomCicInterface, sizeof(g_cdcVcomCicInterface) /
        sizeof(usb_device_interface_struct_t)
    },
    {
        USB_CDC_VCOM_DIC_CLASS,
        USB_CDC_VCOM_DIC_SUBCLASS,
        USB_CDC_VCOM_DIC_PROTOCOL,
        USB_CDC_VCOM_DIC_INTERFACE_INDEX,
    }
};

```

```

        g_cdcVcomDicInterface, sizeof(g_cdcVcomDicInterface) /
    sizeof(usb_device_interface_struct_t)
    },
};

```

`USB_CDC_VCOM_CIC_INTERFACE_INDEX` is the interface index of the control interface in a current configuration. In other words, in the interface descriptor, the interface number is `USB_CDC_VCOM_CIC_INTERFACE_INDEX`.

`USB_CDC_VCOM_DIC_INTERFACE_INDEX` is the interface index of the data interface in a current configuration. In other words, in the interface descriptor, the interface number is `USB_CDC_VCOM_DIC_INTERFACE_INDEX`.

“`g_cdcVcomCicInterface`” is the control interface structure with detailed information. See [Section 4.6](#) section for more information.

“`g_cdcVcomDicInterface`” is the data interface structure with detailed information. See [Section 4.6](#) section for more information.

## 4.6 `usb_device_interface_struct_t`

This structure provides information about each alternate setting interface for the current interface. All structures should be placed in the “`usb_device_descriptor.c`” file.

### Prototype:

```

typedef struct _usb_device_interface_struct
{
    uint8_t
    usb_device_endpoint_list_t
    void*
} usb_device_interface_struct_t;

```

### Description:

- `alternateSetting`: The alternate value of this interface.
- `endpointList`: endpoint list structure. See the `usb_device_endpoint_list_t` structure.
- `classSpecific`: The class-specific structure pointer.

### Prototype:

```

typedef struct _usb_device_endpoint_list
{
    uint8_t
    usb_device_endpoint_struct_t*
} usb_device_endpoint_list_t;

```

### Description:

- `count`: Number of endpoints in the current interface.
- `endpoint`: Endpoint information structure.

This is an example for the composite device MSD + CDC:

### MSD:

```

usb_device_interface_struct_t g_mscDiskInterface[] =
{
{

```

```

        0,
    {
        USB_MSC_DISK_ENDPOINT_COUNT,
        g_mscDiskEndpoints,
    },
};

```

Number “0” holds the alternate setting value of the MSD interface.

`USB_MSC_DISK_ENDPOINT_COUNT` is the endpoint number for MSD interface when the alternate setting is 0.

“`g_mscDiskEndpoints`” is the endpoint detailed information structure. See [Section 4.7](#) section for more information.

CDC:

For control interface:

```

/* Define interface for communication class */
usb_device_interface_struct_t g_cdcVcomCicInterface[] =
{
{
    0,
    {
        USB_CDC_VCOM_CIC_ENDPOINT_COUNT,
        g_cdcVcomCicEndpoints,
    },
}
};

```

Number “0” holds the alternate setting value of the CDC control interface.

`USB_CDC_VCOM_CIC_ENDPOINT_COUNT` is the endpoint number for control interface when the alternate setting is 0.

“`g_cdcVcomCicEndpoints`” is the endpoint detailed information structure. See [Section 4.7](#) section for more information.

For data interface:

```

/* Define interface for data class */
usb_device_interface_struct_t g_cdcVcomDicInterface[] =
{
{
    0,
    {
        USB_CDC_VCOM_DIC_ENDPOINT_COUNT,
        g_cdcVcomDicEndpoints,
    },
}
};

```

Number “0” holds the alternate setting value of the CDC data interface.

`USB_CDC_VCOM_DIC_ENDPOINT_COUNT` is the endpoint number for control interface when the alternate setting is 0.

“`g_cdcVcomDicEndpoints`” is the endpoint detailed information structure. See [Section 4.7](#) section for more information.

## 4.7 usb\_device\_endpoint\_struct\_t

This structure is required for the composite device and provides ep information. All structures should be placed in the “usb\_device\_descriptor.c” file.

### Prototype:

```
typedef struct _usb_device_endpoint_struct
{
    uint8_t endpointAddress; /*! endpoint address */
    uint8_t transferType; /*! endpoint transfer type */
    uint16_t maxPacketSize; /*! endpoint max packet size */
} usb_device_endpoint_struct_t;
```

### Description:

- endpointAddress: Endpoint address (b7, 0 – USB\_OUT, 1 – USB\_IN).
- transferType: The transfer type of this endpoint.
- maxPacketSize: The maximum packet size of this endpoint.

This is an example for the composite device MSD + CDC:

### MSD:

```
usb_device_endpoint_struct_t
g_mscDiskEndpoints[USB_MSC_DISK_ENDPOINT_COUNT] =
{
    {
        USB_MSC_DISK_BULK_IN_ENDPOINT | (USB_IN << 7U),
        USB_ENDPOINT_BULK,
        FS_MSC_DISK_BULK_IN_PACKET_SIZE,
    },
    {
        USB_MSC_DISK_BULK_OUT_ENDPOINT | (USB_OUT << 7U),
        USB_ENDPOINT_BULK,
        FS_MSC_DISK_BULK_OUT_PACKET_SIZE,
    }
};
```

### CDC:

This is CDC class control interface endpoint information.

```
/* Define endpoint for communication class */
usb_device_endpoint_struct_t
g_cdcVcomCicEndpoints[USB_CDC_VCOM_CIC_ENDPOINT_COUNT] =
{
    {
        USB_CDC_VCOM_CIC_INTERRUPT_IN_ENDPOINT | (USB_IN <<
7U),
        USB_ENDPOINT_INTERRUPT,
        HS_CDC_VCOM_BULK_IN_PACKET_SIZE,
    },
}
```

This is the CDC class data interface endpoint information.

```
/* Define endpoint for data class */
usb_device_endpoint_struct_t
g_cdcVcomDicEndpoints[USB_CDC_VCOM_DIC_ENDPOINT_COUNT] =
{
    {
        USB_CDC_VCOM_DIC_BULK_IN_ENDPOINT | (USB_IN << 7U),
        USB_ENDPOINT_BULK,
        FS_CDC_VCOM_BULK_IN_PACKET_SIZE,
    },
    {
        USB_CDC_VCOM_DIC_BULK_OUT_ENDPOINT | (USB_OUT << 7U),
        USB_ENDPOINT_BULK,
        FS_CDC_VCOM_BULK_OUT_PACKET_SIZE,
    },
};
```

## 5 USB descriptor functions

All USB device descriptor and functions are placed in the “usb\_device\_descriptor.c” file.

### 5.1 USB descriptor

The descriptors for each class can be obtained from the class-related examples and class specification. For the composite device, combine multiple class descriptors.

**Note:** *The interface number in the configuration descriptor must be the correct interface number value. The endpoint number value in each endpoint descriptor must be consistent with the structures in [Section 4.7](#).*

### 5.2 USB\_DeviceGetDeviceDescriptor

This function is used to get the device descriptor. All devices must implement this function.

```
usb_status_t USB_DeviceGetDeviceDescriptor(usb_device_handle,
                                         usb_device_get_device_descriptor_struct_t *deviceDescriptor)
{
    deviceDescriptor->buffer = g_UsbDeviceDescriptor;
    deviceDescriptor->length = USB_DESCRIPTOR_LENGTH_DEVICE;
    return kStatus_USB_Success;
}
```

### 5.3 USB\_DeviceGetConfigurationDescriptor

This function is used to get the configuration descriptor. All devices must implement this function.

```
/* Get device configuration descriptor request */
usb_status_t USB_DeviceGetConfigurationDescriptor(
```

```

        usb_device_handle handle,
        usb_device_get_configuration_descriptor_struct_t
        *configurationDescriptor)
{
    if (USB_COMPOSITE_CONFIGURE_INDEX >
configurationDescriptor->configuration)
    {
        configurationDescriptor->buffer =
g_UsbDeviceConfigurationDescriptor;
        configurationDescriptor->length =
USB_DESCRIPTOR_LENGTH_CONFIGURATION_ALL;
        return kStatus_USB_Success;
    }
    return kStatus_USB_InvalidRequest;
}

```

## 5.4 USB\_DeviceGetStringDescriptor

This function is used to get the string descriptor. All devices must implement this function.

```

/* Get device string descriptor request */
usb_status_t USB_DeviceGetStringDescriptor(usb_device_handle
handle,

    usb_device_get_string_descriptor_struct_t *stringDescriptor)
{
    if (stringDescriptor->stringIndex == 0U)
    {
        stringDescriptor->buffer = (uint8_t
*)g_UsbDeviceLanguageList.languageString;
        stringDescriptor->length =
g_UsbDeviceLanguageList.stringLength;
    }
    else
    {
        uint8_t languageId = 0U;
        uint8_t languageIndex = USB_DEVICE_STRING_COUNT;
        for (; languageId < USB_DEVICE_STRING_COUNT; languageId++)
        {
            if (stringDescriptor->languageId ==
g_UsbDeviceLanguageList.languageList[languageId].languageId)
            {
                if (stringDescriptor->stringIndex <
USB_DEVICE_STRING_COUNT)
                {
                    languageIndex = stringDescriptor-
>stringIndex;
                }
                break;
            }
        }
        if (USB_DEVICE_STRING_COUNT == languageIndex)
        {
            return kStatus_USB_InvalidRequest;
        }
        stringDescriptor->buffer = (uint8_t
*)g_UsbDeviceLanguageList.languageList[languageId].string[languageIndex];
    }
}

```

```
        stringDescriptor->length =
    g_UsbDeviceLanguageList.languageList[languageId].length[languageIndex];
}
return kStatus_USB_Success;
}
```

## 5.5 USB\_DeviceGetHidDescriptor

```
/* Get HID descriptor request */
usb_status_t USB_DeviceGetHidDescriptor(usb_device_handle
handle,
usb_device_get_hid_descriptor_struct_t *hidDescriptor)
{
    /* If this request is not supported, return the error
    code "kStatus_USB_InvalidRequest". Otherwise, fill the
    hidDescriptor with the descriptor buffer address and length
    based on the interface number. */
    return kStatus_USB_InvalidRequest;
}
```

## 5.6 USB\_DeviceGetHidReportDescriptor

```
/* Get the HID report descriptor request */
usb_status_t USB_DeviceGetHidReportDescriptor(usb_device_handle
handle,
usb_device_get_hid_report_descriptor_struct_t
*hidReportDescriptor)
{
    if (USB_HID_GENERIC_INTERFACE_INDEX == hidReportDescriptor-
>interfaceNumber)
    {
        hidReportDescriptor->buffer =
g_UsbDeviceHidGenericReportDescriptor;
        hidReportDescriptor->length =
USB_DESCRIPTOR_LENGTH_HID_GENERIC_REPORT;
    }
    else if (USB_HID_KEYBOARD_INTERFACE_INDEX == hidReportDescriptor-
>interfaceNumber)
    {
        hidReportDescriptor->buffer =
g_UsbDeviceHidKeyboardReportDescriptor;
        hidReportDescriptor->length =
USB_DESCRIPTOR_LENGTH_HID_KEYBOARD_REPORT;
    }
    else
    {
        return kStatus_USB_InvalidRequest;
    }
    return kStatus_USB_Success;
}
```

## 5.7 USB\_DeviceGetHidPhysicalDescriptor

```
/* Get the HID physical descriptor request */
usb_status_t USB_DeviceGetHidPhysicalDescriptor(
    usb_device_handle handle,
    usb_device_get_hid_physical_descriptor_struct_t
    *hidPhysicalDescriptor)
{
    /* If this request is not supported, return the error
    code "kStatus_USB_InvalidRequest". Otherwise, fill the
    hidPhysicalDescriptor with the descriptor buffer address and
    length based on the interface number and the physical index.
    */
    return kStatus_USB_InvalidRequest;
}
```

## 5.8 USB\_DeviceSetSpeed

```
/* Because HS and FS descriptors are different, update the
device descriptors and configurations to match the current
speed.
* By default, the device descriptors and configurations are
configured by using FS parameters for both EHCI and KHCI.
* When the EHCI is enabled, the application needs to call this
function to update the device by using current speed.
* The updated information includes the endpoint max packet
size, endpoint interval, and so on. */
usb_status_t USB_DeviceSetSpeed(usb_device_handle handle,
    uint8_t speed)
{
    usb_descriptor_union_t *descriptorHead;
    usb_descriptor_union_t *descriptorTail;
    descriptorHead = (&g_UsbDeviceConfigurationDescriptor[0]);
    descriptorTail = (&g_UsbDeviceConfigurationDescriptor[USB_DESCRIPTOR_LENGTH_CONFIGURATION -
    1U]);
    while (descriptorHead < descriptorTail)
    {
        if (descriptorHead->common.bDescriptorType ==
USB_DESCRIPTOR_TYPE_ENDPOINT)
        {
            if (USB_SPEED_HIGH == speed)
            {
                if (USB_HID_KEYBOARD_ENDPOINT_IN ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK))
                {
                    descriptorHead->endpoint.bInterval =
HS_HID_KEYBOARD_INTERRUPT_IN_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(HS_HID_KEYBOARD_INTERRUPT_IN_PACKET_SIZE);

descriptorHead->endpoint.wMaxPacketSize);
                }
                else if (((descriptorHead-
>endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN)
                {
                    descriptorHead->endpoint.bInterval =
HS_HID_KEYBOARD_INTERRUPT_OUT_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(HS_HID_KEYBOARD_INTERRUPT_OUT_PACKET_SIZE);

descriptorHead->endpoint.wMaxPacketSize);
                }
            }
        }
    }
}
```

```
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) &&
        (USB_HID_GENERIC_ENDPOINT_IN
== (descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
{
    descriptorHead->endpoint.bInterval =
HS_HID_GENERIC_INTERRUPT_IN_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(HS_HID_GENERIC_INTERRUPT_IN_PACKET_SI
descriptorHead->endpoint.wMaxPacketSize);
}
else if (((descriptorHead-
>endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) &&
        (USB_HID_GENERIC_ENDPOINT_OUT
== (descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
{
    descriptorHead->endpoint.bInterval =
HS_HID_GENERIC_INTERRUPT_OUT_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(HS_HID_GENERIC_INTERRUPT_OUT_PACKET_S
descriptorHead->endpoint.wMaxPacketSize);
}
else
{
    if (USB_HID_KEYBOARD_ENDPOINT_IN
== (descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK))
    {
        descriptorHead->endpoint.bInterval =
FS_HID_KEYBOARD_INTERRUPT_IN_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(FS_HID_KEYBOARD_INTERRUPT_IN_PACKET_S
descriptorHead->endpoint.wMaxPacketSize);
}
else if (((descriptorHead-
>endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) &&
        (USB_HID_GENERIC_ENDPOINT_IN
== (descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
{
    descriptorHead->endpoint.bInterval =
FS_HID_GENERIC_INTERRUPT_IN_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(FS_HID_GENERIC_INTERRUPT_IN_PACKET_SI
descriptorHead->endpoint.wMaxPacketSize);
}
```

```
        else if (((descriptorHead->endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) &&
(USB_HID_GENERIC_ENDPOINT_OUT ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
{
    descriptorHead->endpoint.bInterval =
FS_HID_GENERIC_INTERRUPT_OUT_INTERVAL;

    USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(FS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE);

    descriptorHead->endpoint.wMaxPacketSize;
}
}
descriptorHead = (usb_descriptor_union_t *)((uint8_t *)
descriptorHead + descriptorHead->common.bLength);
}
for (int i = 0; i < USB_HID_GENERIC_ENDPOINT_COUNT; i++)
{
    if (USB_SPEED_HIGH == speed)
    {
        if
(g_UsbDeviceHidGenericEndpoints[i].endpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN)
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
= HS_HID_GENERIC_INTERRUPT_IN_PACKET_SIZE;
        }
        else
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
= HS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE;
        }
    }
    else
    {
        if
(g_UsbDeviceHidGenericEndpoints[i].endpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN)
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
= HS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE;
        }
        else
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
= FS_HID_KEYBOARD_INTERRUPT_IN_PACKET_SIZE;
        }
    }
    if (USB_SPEED_HIGH == speed)
    {
        g_UsbDeviceHidKeyboardEndpoints[0].maxPacketSize =
HS_HID_KEYBOARD_INTERRUPT_IN_PACKET_SIZE;
    }
    else
```

```
{  
    g_UsbDeviceHidKeyboardEndpoints[0].maxPacketSize =  
    FS_HID_KEYBOARD_INTERRUPT_IN_PACKET_SIZE;  
}  
return kStatus_USB_Success;  
}
```

## 6 USB stack configurations

Class configuration:

This section describes a use case where two or more of the same classes are used in the composite device.

To reduce the footprint, the released USB stack does not support multiple instances of the same class in the default configuration. If two or more same classes are used in the composite device, the user needs to configure the class.

- For HID class, `USB_DEVICE_CONFIG_HID` must be configured in the `usb_device_config.h`.
- For CDC class, `USB_DEVICE_CONFIG_CDC_ACM` must be configured in the `usb_device_config.h`.
- For MSD class, `USB_DEVICE_CONFIG_MSC` must be configured in the `usb_device_config.h`.
- For AUDIO class, `USB_DEVICE_CONFIG_AUDIO` must be configured in the `usb_device_config.h`.
- For PHDC class, `USB_DEVICE_CONFIG_PHDC` must be configured in the `usb_device_config.h`.
- For VIDEO class, `USB_DEVICE_CONFIG_VIDEO` must be configured in the `usb_device_config.h`.
- For CCID class, `USB_DEVICE_CONFIG_CCID` must be configured in the `usb_device_config.h`.

The value of the configuration depends on use cases and user requirements. For example, for the composite device HID+HID, the `USB_DEVICE_CONFIG_HID` must be set to 2.

**Note:** `USBCFG_DEV_MAX_ENDPOINTS` must not be less than “max used endpoint number + 1”. “max used endpoint number” indicates the maximum endpoint number that the example uses.

## 7 Application template

The redesigned USB stack makes the composite device application easy to implement and aligned with the general device.

### 7.1 Application structure template

For a general device, a demo contains only one class. However, for the composite device, a demo contains more than one class. Likewise, a structure is required to manage the application involving more than one class.

```
typedef struct composite_device_struct  
{
```

```

usb_device_handle           deviceHandle;
class_handle_t              classHandle1;
class_handle_t              classHandle2;
...
class_handle_t              classHandleN;
uint8_t                     speed;
uint8_t                     attach;
uint8_t                     currentConfiguration;
currentInterfaceAlternateSetting[USB_COMPOSITE_INTERFACE_COUNT];
}composite_device_struct_t;

```

deviceHandle: The handle pointer to a device, which is returned by the `USB_DeviceClassInit`.

speed: Speed of the USB device. `USB_SPEED_FULL`/`USB_SPEED_LOW`/`USB_SPEED_HIGH`.

attach: Indicates whether the device is attached or not.

currentConfiguration: The current device configuration value.

currentInterfaceAlternateSetting: The current alternate setting for each interface.

classHandleN: The pointer to a class.

This is an example for a composite device HID mouse + HID keyboard:

This structure is in the “composite.h” file.

#### Prototype:

```

typedef struct _usb_device_composite_struct
{
    usb_device_handle           deviceHandle;
    class_handle_t              hidMouseHandle;
    class_handle_t              hidKeyboardHandle;
    uint8_t                     speed;
    uint8_t                     attach;
    uint8_t                     currentConfiguration;
    currentInterfaceAlternateSetting[USB_COMPOSITE_INTERFACE_COUNT];
} usb_device_composite_struct_t;

```

## 7.2 Application initialization process

1. Before initializing the USB stack by calling the `USB_DeviceClassInit` function, the `usb_device_class_config_list_struct_t` and `usb_device_class_config_struct_t` are assigned values respectively. For example, for MSC + CDC, the steps are as follows:
  - Declare the `g_compositeDeviceConfigList` as global variables of the type `usb_device_class_config_list_struct_t`.

```

usb_device_class_config_list_struct_t
g_compositeDeviceConfigList =
{
    g_compositeDevice,
    USB_DeviceCallback,
    2,
};

```

- Declare the g\_compositeDevice as global variables of the type `usb_device_class_config_struct_t`.

```
usb_device_class_config_struct_t g_compositeDevice[2] =
{
    {
        {
            USB_DeviceCdcVcomCallback,
            (class_handle_t)NULL,
            &g_UsbDeviceCdcVcomConfig,
        },
        {
            USB_DeviceMscCallback,
            (class_handle_t)NULL,
            &g_mscDiskClass,
        }
    };
}
```

- Add a function for the USB device ISR.

For EHCI,

```
#if defined(USB_DEVICE_CONFIG_EHCI) &&
    (USB_DEVICE_CONFIG_EHCI > 0U)
void USBHS_IRQHandler(void)
{
    USB_DeviceEhciIsrFunction(g_composite.deviceHandle);
}
#endif
```

For KHC1,

```
#if defined(USB_DEVICE_CONFIG_KHCI) &&
    (USB_DEVICE_CONFIG_KHCI > 0U)
void USBO_IRQHandler(void)
{
    USB_DeviceKhciIsrFunction(g_composite.deviceHandle);
}
#endif
```

For LPC IP3511,

```
#if defined(USB_DEVICE_CONFIG_LPC3511IP) &&
    (USB_DEVICE_CONFIG_LPC3511IP > 0U)
void USBO_IRQHandler(void)
{
    USB_DeviceLpc3511IpIsrFunction
    (g_composite.deviceHandle);
}
#endif
```

## 2. Enable the USB device clock.

For EHCI,

```
CLOCK_EnableUsbhs0Clock(kCLOCK_UsbSrcP110,
    CLOCK_GetFreq(kCLOCK_P11F11SelClk));
USB_EhciPhyInit(CONTROLLER_ID, BOARD_XTAL0_CLK_HZ);
```

For KHC1,

```
#if ((defined
    FSL_FEATURE_USB_KHCI_IRC48M_MODULE_CLOCK_ENABLED) &&
    (FSL_FEATURE_USB_KHCI_IRC48M_MODULE_CLOCK_ENABLED))
CLOCK_EnableUsbfs0Clock(kCLOCK_UsbSrcIrc48M, 48000000U);
#else
```

```
CLOCK_EnableUsbfs0Clock(kCLOCK_UsbSrcP110,
    CLOCK_GetFreq(kCLOCK_P11F11SelClk));
#endif /* FSL_FEATURE_USB_KHCI_IRC48M_MODULE_CLOCK_ENABLED */
```

For LPC IP3511,

```
CLOCK_EnableUsbfs0Clock(kCLOCK_UsbSrcFro,
    CLOCK_GetFreq(kCLOCK_FroHf));
```

### 3. Call the `USB_DeviceClassInit` function.

```
if (kStatus_USB_Success != USB_DeviceClassInit(CONTROLLER_ID,
    &g_compositeDeviceConfigList, &g_composite.deviceHandle))
{
    usb_echo("USB device composite demo init failed\r\n");
    return;
}
else
{
    usb_echo("USB device composite demo\r\n");
    ....
}
```

### 4. Get a handle for each class. For example, CDC virtual com:

```
g_composite.cdcVcom.cdcAcmHandle =
    g_compositeDeviceConfigList.config[0].classHandle;
```

MSC ramdisk:

```
g_composite.mscDisk.mscHandle =
    g_compositeDeviceConfigList.config[1].classHandle;
```

### 5. Initialize each class application.

Such as,

CDC virtual com:

```
USB_DeviceCdcVcomInit(&g_composite);
```

MSC ramdisk:

```
USB_DeviceMscDiskInit(&g_composite);
```

### 6. Set the interrupt priority and enable the USB device interrupt

```
NVIC_SetPriority((IRQn_Type)irqNo,
    USB_DEVICE_INTERRUPT_PRIORITY);
NVIC_EnableIRQ((IRQn_Type)irqNo);
```

### 7. Enable the USB device funtionally:

```
USB_DeviceRun(g_composite.deviceHandle);
```

## 8 HID keyboard + HID generic composite device example

In this section, HID keyboard + HID generic composite device are used as an example.

### 8.1 USB composite device structure examples

```
/* Two HID classes */
```

```
usb_device_class_config_list_struct_t
g_UsbDeviceCompositeConfigList =
{
    g_CompositeClassConfig,
    USB_DeviceCallback,
    2U,
};

/* Two HID classes definition */
usb_device_class_config_struct_t g_CompositeClassConfig[2] =
{
    {
        USB_DeviceHidKeyboardCallback,
        (class_handle_t)NULL,
        &g_UsbDeviceHidKeyboardConfig,
    },
    {
        USB_DeviceHidGenericCallback,
        (class_handle_t)NULL,
        &g_UsbDeviceHidGenericConfig,
    }
};

/* HID generic device config */
usb_device_class_struct_t g_UsbDeviceHidGenericConfig =
{
    g_UsbDeviceHidGenericInterfaceList, /* The interface list
of the HID generic */
    kUSB_DeviceClassTypeHid,           /* The HID class type
*/
    USB_DEVICE_CONFIGURATION_COUNT,   /* The
configuration count */
};

/* HID generic device interface list */
usb_device_interface_list_t
g_UsbDeviceHidGenericInterfaceList[USB_DEVICE_CONFIGURATION_COUNT] =
{
    {
        USB_HID_GENERIC_INTERFACE_COUNT, /* The interface count
of the HID generic */
        g_UsbDeviceHidGenericInterfaces, /* The
interfaces handle */
    },
};

/* HID generic device interfaces */
usb_device_interfaces_struct_t
g_UsbDeviceHidGenericInterfaces[USB_HID_GENERIC_INTERFACE_COUNT] =
{
    USB_HID_GENERIC_CLASS,           /* HID generic class code
*/
    USB_HID_GENERIC_SUBCLASS,        /* HID generic subclass
code */
    USB_HID_GENERIC_PROTOCOL,        /* HID generic protocol
code */
    USB_HID_GENERIC_INTERFACE_INDEX, /* The interface number of
the HID generic */
    g_UsbDeviceHidGenericInterface,  /* Interfaces
handle */
    sizeof(g_UsbDeviceHidGenericInterface) /
    sizeof(usb_device_interface_struct_t),
};
```

```
};

/* HID generic device interface and alternate setting device
   information */
usb_device_interface_struct_t g_UsbDeviceHidGenericInterface[] =
{
{
    {
        0U, /* The alternate setting of the interface */
        {
            USB_HID_GENERIC_ENDPOINT_COUNT, /* Endpoint count
            */
            g_UsbDeviceHidGenericEndpoints, /* Endpoints
            handle */
        },
    }
};

/* HID generic device endpoint information for interface
   USB_HID_GENERIC_INTERFACE_INDEX and alternate setting is 0. */
usb_device_endpoint_struct_t
g_UsbDeviceHidGenericEndpoints[USB_HID_GENERIC_ENDPOINT_COUNT] =
{
    /* HID generic interrupt IN pipe */
    {
        USB_HID_GENERIC_ENDPOINT_IN | (USB_IN <<
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_SHIFT),
        USB_ENDPOINT_INTERRUPT,
        FS_HID_GENERIC_INTERRUPT_IN_PACKET_SIZE,
    },
    /* HID generic interrupt OUT pipe */
    {
        USB_HID_GENERIC_ENDPOINT_OUT | (USB_OUT <<
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_SHIFT),
        USB_ENDPOINT_INTERRUPT,
        FS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE,
    },
};

/* HID keyboard device config */
usb_device_class_struct_t g_UsbDeviceHidKeyboardConfig =
{
    g_UsbDeviceHidKeyboardInterfaceList, /* The interface list
of the HID keyboard */
    kUSB_DeviceClassTypeHid, /* The HID class type
*/
    USB_DEVICE_CONFIGURATION_COUNT, /* The
configuration count */
};

/* HID keyboard device interface list */
usb_device_interface_list_t
g_UsbDeviceHidKeyboardInterfaceList[USB_DEVICE_CONFIGURATION_COUNT] =
{
{
    {
        USB_HID_KEYBOARD_INTERFACE_COUNT, /* The interface
count of the HID keyboard */
        g_UsbDeviceHidKeyboardInterfaces, /* The
interfaces handle */
    },
},
};

/* HID generic device interfaces */
}
```

```

usb_device_interfaces_struct_t
g_UsbDeviceHidKeyboardInterfaces[USB_HID_KEYBOARD_INTERFACE_COUNT]
=
{
    USB_HID_KEYBOARD_CLASS, /* HID keyboard class
    code */
    USB_HID_KEYBOARD_SUBCLASS, /* HID keyboard subclass
    code */
    USB_HID_KEYBOARD_PROTOCOL, /* HID keyboard protocol
    code */
    USB_HID_KEYBOARD_INTERFACE_INDEX, /* The interface number
    of the HID keyboard */
    g_UsbDeviceHidKeyboardInterface, /* Interfaces
    handle */
    sizeof(g_UsbDeviceHidKeyboardInterface) /
    sizeof(usb_device_interface_struct_t),
};

/* HID generic device interface and alternate setting device
information */
usb_device_interface_struct_t g_UsbDeviceHidKeyboardInterface[]
=
{
    {
        0U, /* The alternate setting of the interface */
        {
            USB_HID_KEYBOARD_ENDPOINT_COUNT, /* Endpoint count
            */
            g_UsbDeviceHidKeyboardEndpoints, /* *
            Endpoints handle */
            },
        }
    };
/* HID generic device endpoint information for interface
USB_HID_GENERIC_INTERFACE_INDEX and alternate setting is 0. */
usb_device_endpoint_struct_t
g_UsbDeviceHidKeyboardEndpoints[USB_HID_KEYBOARD_ENDPOINT_COUNT]
=
{
    /* HID keyboard interrupt IN pipe */
    {
        USB_HID_KEYBOARD_ENDPOINT_IN | (USB_IN <<
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_SHIFT),
        USB_ENDPOINT_INTERRUPT,
        FS_HID_KEYBOARD_INTERRUPT_IN_PACKET_SIZE,
    },
};

```

## 8.2 USB composite device descriptor examples

Modify the vendor ID and product ID for the device descriptor in the “usb\_device\_descriptor.c” file.

Change the interface number as shown in the configuration descriptor in the “usb\_device\_descriptor.c” file.

Merge the HID keyboard and HID generic configuration descriptor (in the “usb\_device\_descriptor.c” file) from the HID mouse + HID keyboard example and hid\_generic example and change the endpoint number to be consistent with section [Section 8.1](#).

### 8.2.1 USB\_DeviceGetDeviceDescriptor

This function is used to get the device descriptor. All devices must implement this function.

```
usb_status_t USB_DeviceGetDeviceDescriptor(usb_device_handle  
                                         handle,  
  
                                         usb_device_get_device_descriptor_struct_t *deviceDescriptor)  
{  
    deviceDescriptor->buffer = g_UsbDeviceDescriptor;  
    deviceDescriptor->length = USB_DESCRIPTOR_LENGTH_DEVICE;  
    return kStatus_USB_Success;  
}
```

### 8.2.2 USB\_DeviceGetConfigurationDescriptor

This function is used to get the configuration descriptor. All devices must implement this function.

```
/* Get device configuration descriptor request */  
usb_status_t USB_DeviceGetConfigurationDescriptor(  
    usb_device_handle handle,  
    usb_device_get_configuration_descriptor_struct_t  
    *configurationDescriptor)  
{  
    if (USB_COMPOSITE_CONFIGURE_INDEX >  
        configurationDescriptor->configuration)  
    {  
        configurationDescriptor->buffer =  
            g_UsbDeviceConfigurationDescriptor;  
        configurationDescriptor->length =  
            USB_DESCRIPTOR_LENGTH_CONFIGURATION_ALL;  
        return kStatus_USB_Success;  
    }  
    return kStatus_USB_InvalidRequest;  
}
```

### 8.2.3 USB\_DeviceGetStringDescriptor

This function is used to get the string descriptor. All devices must implement this function.

```
/* Get device string descriptor request */  
usb_status_t USB_DeviceGetStringDescriptor(usb_device_handle  
                                         handle,  
  
                                         usb_device_get_string_descriptor_struct_t *stringDescriptor)  
{  
    if (stringDescriptor->stringIndex == 0U)  
    {  
        stringDescriptor->buffer = (uint8_t  
        *)g_UsbDeviceLanguageList.languageString;  
        stringDescriptor->length =  
            g_UsbDeviceLanguageList.stringLength;  
    }  
    else
```

```

{
    uint8_t languageId = 0U;
    uint8_t languageIndex = USB_DEVICE_STRING_COUNT;
    for (; languageId < USB_DEVICE_STRING_COUNT; languageId++)
    {
        if (stringDescriptor->languageId ==
g_UsbDeviceLanguageList.languageList[languageId].languageId)
        {
            if (stringDescriptor->stringIndex <
USB_DEVICE_STRING_COUNT)
            {
                languageIndex = stringDescriptor-
>stringIndex;
            }
            break;
        }
    }
    if (USB_DEVICE_STRING_COUNT == languageIndex)
    {
        return kStatus_USB_InvalidRequest;
    }
    stringDescriptor->buffer = (uint8_t
*)g_UsbDeviceLanguageList.languageList[languageId].string[languageIndex]
    stringDescriptor->length =
g_UsbDeviceLanguageList.languageList[languageId].length[languageIndex];
}
return kStatus_USB_Success;
}

```

#### 8.2.4 USB\_DeviceGetHidDescriptor

```

/* Get HID descriptor request */
usb_status_t USB_DeviceGetHidDescriptor(usb_device_handle
handle,
usb_device_get_hid_descriptor_struct_t *hidDescriptor)
{
    /* If this request is not supported, return the error
    code "kStatus_USB_InvalidRequest". Otherwise, fill the
    hidDescriptor with the descriptor buffer address and length
    based on the interface number. */
    return kStatus_USB_InvalidRequest;
}

```

#### 8.2.5 USB\_DeviceGetHidReportDescriptor

```

/* Get the HID report descriptor request */
usb_status_t USB_DeviceGetHidReportDescriptor(usb_device_handle
handle,
usb_device_get_hid_report_descriptor_struct_t
*hidReportDescriptor)
{
    if (USB_HID_GENERIC_INTERFACE_INDEX == hidReportDescriptor-
>interfaceNumber)
    {

```

```

        hidReportDescriptor->buffer =
g_UsbDeviceHidGenericReportDescriptor;
        hidReportDescriptor->length =
USB_DESCRIPTOR_LENGTH_HID_GENERIC_REPORT;
    }
    else if (USB_HID_KEYBOARD_INTERFACE_INDEX ==
hidReportDescriptor->interfaceNumber)
    {
        hidReportDescriptor->buffer =
g_UsbDeviceHidKeyboardReportDescriptor;
        hidReportDescriptor->length =
USB_DESCRIPTOR_LENGTH_HID_KEYBOARD_REPORT;
    }
    else
    {
        return kStatus_USB_InvalidRequest;
    }
    return kStatus_USB_Success;
}

```

### 8.2.6 USB\_DeviceGetHidPhysicalDescriptor

```

/* Get the HID physical descriptor request */
usb_status_t USB_DeviceGetHidPhysicalDescriptor(
    usb_device_handle handle,
    usb_device_get_hid_physical_descriptor_struct_t
    *hidPhysicalDescriptor)
{
    /* If this request is not supported, return the error
    code "kStatus_USB_InvalidRequest". Otherwise, fill the
    hidPhysicalDescriptor with the descriptor buffer address and
    length based on the interface number and the physical index.
    */
    return kStatus_USB_InvalidRequest;
}

```

### 8.2.7 USB\_DeviceSetSpeed

```

/* Because HS and FS descriptors are different, update the
device descriptors and configurations to match the current
speed.
* By default, the device descriptors and configurations are
configured by using FS parameters for both EHCI and KHCI.
* When the EHCI is enabled, the application needs to call this
function to update the device by using current speed.
* The updated information includes the endpoint max packet
size, endpoint interval, and so on. */
usb_status_t USB_DeviceSetSpeed(usb_device_handle handle,
    uint8_t speed)
{
    usb_descriptor_union_t *descriptorHead;
    usb_descriptor_union_t *descriptorTail;
    descriptorHead = (usb_descriptor_union_t
    *) &g_UsbDeviceConfigurationDescriptor[0];
    descriptorTail = (usb_descriptor_union_t *)
    (&g_UsbDeviceConfigurationDescriptor[USB_DESCRIPTOR_LENGTH_CONFIGURATION_-
    - 1U]);

```

```
        while (descriptorHead < descriptorTail)
        {
            if (descriptorHead->common.bDescriptorType ==
USB_DESCRIPTOR_TYPE_ENDPOINT)
            {
                if (USB_SPEED_HIGH == speed)
                {
                    if (USB_HID_KEYBOARD_ENDPOINT_IN ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK))
                    {
                        descriptorHead->endpoint.bInterval =
HS_HID_KEYBOARD_INTERRUPT_IN_INTERVAL;

                        USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(HS_HID_KEYBOARD_INTERRUPT_IN_PACKET_SIZE,
descriptorHead->endpoint.wMaxPacketSize);
                    }
                    else if (((descriptorHead-
>endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) &&
(USB_HID_GENERIC_ENDPOINT_IN ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
                    {
                        descriptorHead->endpoint.bInterval =
HS_HID_GENERIC_INTERRUPT_IN_INTERVAL;

                        USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(HS_HID_GENERIC_INTERRUPT_IN_PACKET_SIZE,
descriptorHead->endpoint.wMaxPacketSize);
                    }
                    else if (((descriptorHead-
>endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) &&
(USB_HID_GENERIC_ENDPOINT_OUT ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
                    {
                        descriptorHead->endpoint.bInterval =
HS_HID_GENERIC_INTERRUPT_OUT_INTERVAL;

                        USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(HS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE,
descriptorHead->endpoint.wMaxPacketSize);
                    }
                }
                else
                {
                    if (USB_HID_KEYBOARD_ENDPOINT_IN ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK))
                    {
                        descriptorHead->endpoint.bInterval =
FS_HID_KEYBOARD_INTERRUPT_IN_INTERVAL;
```

```
USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(FS_HID_KEYBOARD_INTERRUPT_IN_PACKET_SIZE);
descriptorHead->endpoint.wMaxPacketSize);
}
else if (((descriptorHead->endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN) &&
(USB_HID_GENERIC_ENDPOINT_IN ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
{
    descriptorHead->endpoint.bInterval =
FS_HID_GENERIC_INTERRUPT_IN_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(FS_HID_GENERIC_INTERRUPT_IN_PACKET_SIZE);
descriptorHead->endpoint.wMaxPacketSize);
}
else if (((descriptorHead->endpoint.bEndpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) ==
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_OUT) &&
(USB_HID_GENERIC_ENDPOINT_OUT ==
(descriptorHead->endpoint.bEndpointAddress &
USB_ENDPOINT_NUMBER_MASK)))
{
    descriptorHead->endpoint.bInterval =
FS_HID_GENERIC_INTERRUPT_OUT_INTERVAL;

USB_SHORT_TO_LITTLE_ENDIAN_ADDRESS(FS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE);
descriptorHead->endpoint.wMaxPacketSize);
}
descriptorHead = (usb_descriptor_union_t *)((uint8_t *)
descriptorHead + descriptorHead->common.bLength);
}
for (int i = 0U; i < USB_HID_GENERIC_ENDPOINT_COUNT; i++)
{
    if (USB_SPEED_HIGH == speed)
    {
        if
(g_UsbDeviceHidGenericEndpoints[i].endpointAddress &
USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN)
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
= HS_HID_GENERIC_INTERRUPT_IN_PACKET_SIZE;
        }
        else
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
= HS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE;
        }
    }
}
```

```

    {
        if
        (g_UsbDeviceHidGenericEndpoints[i].endpointAddress &
        USB_DESCRIPTOR_ENDPOINT_ADDRESS_DIRECTION_IN)
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
            = HS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE;
        }
        else
        {
            g_UsbDeviceHidGenericEndpoints[i].maxPacketSize
            = FS_HID_GENERIC_INTERRUPT_OUT_PACKET_SIZE;
        }
    }
    if (USB_SPEED_HIGH == speed)
    {
        g_UsbDeviceHidKeyboardEndpoints[0].maxPacketSize =
        HS_KEYBOARD_INTERRUPT_IN_PACKET_SIZE;
    }
    else
    {
        g_UsbDeviceHidKeyboardEndpoints[0].maxPacketSize =
        FS_KEYBOARD_INTERRUPT_IN_PACKET_SIZE;
    }
    return kStatus_USB_Success;
}

```

## 8.3 USB composite device application example

### 8.3.1 Class configuration

USB\_DEVICE\_CONFIG\_HID is set to 2 in `usb_device_config.h`

USB\_DEVICE\_CONFIG\_ENDPOINTS is set to 4 in `usb_device_config.h`

### 8.3.2 HID + HID Application structure

```

typedef struct _usb_device_composite_struct
{
    usb_device_handle                                deviceHandle;
    class_handle_t                                    hidKeyboardHandle;
    class_handle_t                                    hidGenericHandle;
    uint8_t                                         speed;
    uint8_t                                         attach;
    uint8_t                                         currentConfiguration;
    uint8_t                                         currentInterfaceAlternateSetting[USB_COMPOSITE_INTERFACE_COUNT];
} usb_device_composite_struct_t;
/* HID keyboard structure */
typedef struct _usb_device_hid_keyboard_struct
{
    uint8_t                                         buffer[USB_HID_KEYBOARD_IN_BUFFER_LENGTH];
    uint8_t                                         idleRate;
} usb_device_hid_keyboard_struct_t;

```

```
/* HID generic structure */
typedef struct _usb_device_hid_generic_struct
{
    uint32_t                      buffer[2]
    [USB_HID_GENERIC_IN_BUFFER_LENGTH>>2];
    uint8_t                         bufferIndex;
    uint8_t                         idleRate;
} usb_device_hid_generic_struct_t;
```

### 8.3.3 HID + HID application

#### 1. Define and initialize the configuration structure.

```
static usb_device_composite_struct_t g_UsbDeviceComposite;
usb_device_class_struct_t g_UsbDeviceHidGenericConfig;
usb_device_class_struct_t g_UsbDeviceHidKeyboardConfig;
usb_device_class_config_struct_t g_CompositeClassConfig[2] =
{
    {
        USB_DeviceHidKeyboardCallback,
        (class_handle_t)NULL,
        &g_UsbDeviceHidKeyboardConfig,
    },
    {
        USB_DeviceHidGenericCallback,
        (class_handle_t)NULL,
        &g_UsbDeviceHidGenericConfig,
    }
};
usb_device_class_config_list_struct_t
g_UsbDeviceCompositeConfigList =
{
    g_CompositeClassConfig,
    USB_DeviceCallback,
    2U,
};
```

#### 2. Add USB ISR.

```
#if defined(USB_DEVICE_CONFIG_EHCI) &&
    (USB_DEVICE_CONFIG_EHCI > 0U)
void USBHS_IRQHandler(void)
{
    USB_DeviceEhciIsrFunction(g_UsbDeviceComposite.deviceHandle);
}
#endif
#if defined(USB_DEVICE_CONFIG_KHCI) &&
    (USB_DEVICE_CONFIG_KHCI > 0U)
void USBO_IRQHandler(void)
{
    USB_DeviceKhciIsrFunction(g_UsbDeviceComposite.deviceHandle);
}
#endif
#if defined(USB_DEVICE_CONFIG_LPC3511IP) &&
    (USB_DEVICE_CONFIG_LPC3511IP > 0U)
void USBO_IRQHandler(void)
{
    USB_DeviceLpc3511IpIsrFunction(g_UsbDeviceHidMouse.deviceHandle);
}
#endif
```

3. Enable the USB device clock.

```
#if defined(USB_DEVICE_CONFIG_EHCI) &&
    (USB_DEVICE_CONFIG_EHCI > 0U)
        CLOCK_EnableUsbhs0Clock(kCLOCK_UsbSrcP110,
        CLOCK_GetFreq(kCLOCK_P11F11SelClk));
        USB_EhciPhyInit(CONTROLLER_ID, BOARD_XTAL0_CLK_HZ);
#endif
#if defined(USB_DEVICE_CONFIG_KHCI) &&
    (USB_DEVICE_CONFIG_KHCI > 0U)
#endif
#if (!defined(FSL_FEATURE_USB_KHCI_IRC48M_MODULE_CLOCK_ENABLED) &&
    (FSL_FEATURE_USB_KHCI_IRC48M_MODULE_CLOCK_ENABLED))
    CLOCK_EnableUsbfs0Clock(kCLOCK_UsbSrcIrc48M, 48000000U);
#else
    CLOCK_EnableUsbfs0Clock(kCLOCK_UsbSrcP110,
    CLOCK_GetFreq(kCLOCK_P11F11SelClk));
#endif/* FSL_FEATURE_USB_KHCI_IRC48M_MODULE_CLOCK_ENABLED */
#endif
#if defined(USB_DEVICE_CONFIG_LPC3511IP) &&
    (USB_DEVICE_CONFIG_LPC3511IP > 0U)
    CLOCK_EnableUsbfs0Clock(kCLOCK_UsbSrcFro,
    CLOCK_GetFreq(kCLOCK_FroHf));
#endif
```

4. Set the default state.

```
g_UsbDeviceComposite.speed = USB_SPEED_FULL;
g_UsbDeviceComposite.attach = 0U;
g_UsbDeviceComposite.hidGenericHandle = (class_handle_t)NULL;
g_UsbDeviceComposite.hidKeyboardHandle =
    (class_handle_t)NULL;
g_UsbDeviceComposite.deviceHandle = NULL;
```

5. Initialize the USB device.

```
if (kStatus_USB_Success !=
    USB_DeviceClassInit(CONTROLLER_ID,
    &g_UsbDeviceCompositeConfigList,
    &g_UsbDeviceComposite.deviceHandle))
{
    usb_echo("USB device composite demo init failed\r\n");
    return;
}
else
{
    usb_echo("USB device composite demo\r\n");
    ...
}
```

6. Save each class handle when the device is initialized successfully.

```
/* Get the HID keyboard class handle */
g_UsbDeviceComposite.hidKeyboardHandle =
    g_UsbDeviceCompositeConfigList.config[0].classHandle;
/* Get the HID generic class handle */
g_UsbDeviceComposite.hidGenericHandle =
    g_UsbDeviceCompositeConfigList.config[1].classHandle;
```

7. Initialize the HID keyboard and HID generic application.

```
USB_DeviceHidKeyboardInit(&g_UsbDeviceComposite);
```

```

USB_DeviceHidGenericInit(&g_UsbDeviceComposite);

8. Set the device ISR priority and enable the device interrupt.

    NVIC_SetPriority((IRQn_Type)irqNumber,
        USB_DEVICE_INTERRUPT_PRIORITY);
    NVIC_EnableIRQ((IRQn_Type)irqNumber);

9. Start the device functionality.

    USB_DeviceRun(g_UsbDeviceComposite.deviceHandle);

10. Poll the device task when the "USB_DEVICE_CONFIG_USE_TASK" is non-zero.
    Poll the HID keyboard and HID generic task when these tasks are implemented.

#if USB_DEVICE_CONFIG_USE_TASK
#if defined(USB_DEVICE_CONFIG_EHCI) &&
    (USB_DEVICE_CONFIG_EHCI > 0U)

    USB_DeviceEhciTaskFunction(g_UsbDeviceComposite.deviceHandle);
#endif
#if defined(USB_DEVICE_CONFIG_KHCI) &&
    (USB_DEVICE_CONFIG_KHCI > 0U)

    USB_DeviceKhciTaskFunction(g_UsbDeviceComposite.deviceHandle);
#endif
#if defined(USB_DEVICE_CONFIG_LPC3511IP) &&
    (USB_DEVICE_CONFIG_LPC3511IP > 0U)

    USB_DeviceLpc3511IpTaskFunction(g_UsbDeviceHidMouse.deviceHandle);
#endif
#endif

```

## 9 Revision history

This table summarizes revisions to this document.

**Table 1. Revision history**

Revision number	Date	Substantive changes
0	12/2014	Initial release
1	04/2015	Substantive changes
2	09/2015	Section 5.3, Section 6, Section 8.2.2, Section 8.3.1
3	11/2015	Updated for KV5x release
4	01/2016	Updated Section 1
5	09/2016	Added LPC content for release
6	03/2017	Updates for MCUXpresso SDK release
7	11/2017	Updates for MCUXpresso SDK 2.3.0 release
8	05/2018	Updated Section 4.5, "usb_device_interfaces_struct_t", for MCUXpresso SDK 2.4.0 release
9	12/2018	Updated Section 8.3, "USB composite device application example" for MCUXpresso SDK 2.5.0
10	06/2019	Updated 'Overview' section for MCUXpresso SDK 2.6.0

**Table 1. Revision history...continued**

Revision number	Date	Substantive changes
11	16 June 2020	Updated for MCUXpresso SDK 2.8.0
12	01 June 2021	Updated for MCUXpresso SDK 2.10.0
13	11 July 2022	Editorial and layout updates.

## 10 Legal information

### 10.1 Definitions

**Draft** — A draft status on a document indicates that the content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included in a draft version of a document and shall have no liability for the consequences of use of such information.

### 10.2 Disclaimers

**Limited warranty and liability** — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

**Right to make changes** — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

**Suitability for use** — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

**Applications** — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

**Terms and conditions of commercial sale** — NXP Semiconductors products are sold subject to the general terms and conditions of commercial sale, as published at <http://www.nxp.com/profile/terms>, unless otherwise agreed in a valid written individual agreement. In case an individual agreement is concluded only the terms and conditions of the respective agreement shall apply. NXP Semiconductors hereby expressly objects to applying the customer's general terms and conditions with regard to the purchase of NXP Semiconductors products by customer.

**Export control** — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

**Suitability for use in non-automotive qualified products** — Unless this data sheet expressly states that this specific NXP Semiconductors product is automotive qualified, the product is not suitable for automotive use. It is neither qualified nor tested in accordance with automotive testing or application requirements. NXP Semiconductors accepts no liability for inclusion and/or use of non-automotive qualified products in automotive equipment or applications.

In the event that customer uses the product for design-in and use in automotive applications to automotive specifications and standards, customer (a) shall use the product without NXP Semiconductors' warranty of the product for such automotive applications, use and specifications, and (b) whenever customer uses the product for automotive applications beyond NXP Semiconductors' specifications such use shall be solely at customer's own risk, and (c) customer fully indemnifies NXP Semiconductors for any liability, damages or failed product claims resulting from customer design and use of the product for automotive applications beyond NXP Semiconductors' standard warranty and NXP Semiconductors' product specifications.

**Translations** — A non-English (translated) version of a document, including the legal information in that document, is for reference only. The English version shall prevail in case of any discrepancy between the translated and English versions.

**Security** — Customer understands that all NXP products may be subject to unidentified vulnerabilities or may support established security standards or specifications with known limitations. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP.

NXP has a Product Security Incident Response Team (PSIRT) (reachable at [PSIRT@nxp.com](mailto:PSIRT@nxp.com)) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

### 10.3 Trademarks

Notice: All referenced brands, product names, service names, and trademarks are the property of their respective owners.

**NXP** — wordmark and logo are trademarks of NXP B.V.

## Contents

<b>1</b>	<b>Overview</b>	<b>2</b>
<b>2</b>	<b>Introduction</b>	<b>2</b>
<b>3</b>	<b>Setup</b>	<b>2</b>
3.1	Design steps	2
<b>4</b>	<b>USB composite device structures</b>	<b>3</b>
4.1	usb_device_class_config_list_struct_t	3
4.2	usb_device_class_config_struct_t	3
4.3	usb_device_class_struct_t	4
4.4	usb_device_interface_list_t	4
4.5	usb_device_interfaces_struct_t	4
4.6	usb_device_interface_struct_t	6
4.7	usb_device_endpoint_struct_t	8
<b>5</b>	<b>USB descriptor functions</b>	<b>9</b>
5.1	USB descriptor	9
5.2	USB_DeviceGetDeviceDescriptor	9
5.3	USB_DeviceGetConfigurationDescriptor	9
5.4	USB_DeviceGetStringDescriptor	10
5.5	USB_DeviceGetHidDescriptor	11
5.6	USB_DeviceGetHidReportDescriptor	11
5.7	USB_DeviceGetHidPhysicalDescriptor	12
5.8	USB_DeviceSetSpeed	12
<b>6</b>	<b>USB stack configurations</b>	<b>15</b>
<b>7</b>	<b>Application template</b>	<b>15</b>
7.1	Application structure template	15
7.2	Application initialization process	16
<b>8</b>	<b>HID keyboard + HID generic composite device example</b>	<b>18</b>
8.1	USB composite device structure examples	18
8.2	USB composite device descriptor examples	21
8.2.1	USB_DeviceGetDeviceDescriptor	22
8.2.2	USB_DeviceGetConfigurationDescriptor	22
8.2.3	USB_DeviceGetStringDescriptor	22
8.2.4	USB_DeviceGetHidDescriptor	23
8.2.5	USB_DeviceGetHidReportDescriptor	23
8.2.6	USB_DeviceGetHidPhysicalDescriptor	24
8.2.7	USB_DeviceSetSpeed	24
8.3	USB composite device application example	27
8.3.1	Class configuration	27
8.3.2	HID + HID Application structure	27
8.3.3	HID + HID application	28
<b>9</b>	<b>Revision history</b>	<b>30</b>
<b>10</b>	<b>Legal information</b>	<b>32</b>

Please be aware that important notices concerning this document and the product(s) described herein, have been included in section 'Legal information'.